

WEC Manufacturing

1922 Exeter Rd. Suite 8-A
Germantown, TN 38138
Phone: 901-367-3922
Fax: 901-367-3923

Preparation Instructions

Any loose items like slope tops and ends should be laid on the floor do not stack or lean against a walls.

Check that all materials completely as soon as they arrive on site. Check items against packing list and layouts provided. If you are missed any items or the product is damage please contact your dealer immediately.

Before you beginning the locker installation process, a complete inspection of the job site should be done. All areas in which lockers will be placed should be inspected. Make sure to check for any variations in the walls and floor surfaces.

Any variations in the walls that the lockers will be attached to should be addressed prior to beginning the installation process.

If lockers were ordered with a base, the base will be able to float over any low spots in the floor. Shimming may be required to ensure that the base sits evenly and securely on the floor.

Make sure the area is clean and free of any debris. If the installation of the lockers is directly to the floor, be sure to sweep the area clean of the debris before beginning.

Once the site inspection and any preparations are completed, the installation is ready to beginning.